

Roller Shutters, Doors & Motors, Components, Roll formed sections, Steel security & Emergency exit doors

Basic Keyswitch Wiring, Please note this information is intended as a guide only and some switch's may vary,

Points to Note,

This Method is the most common way to wire a tube motor, However there is 230v Present at the Key switch which may not be suitable for all Applications,

This is down to site risk assement,

Low voltage Key switch wiring can be achieved via use of our PM1 Unit,

Wiring of the Key switch should always be done with correct size and type of cable for the load and situation,

Use of multiple motors from a single key switch is not recommended, a suitable group control should be used,

Use of third party latching key switch's is also not recommended,

Key Switch,

Basic Wiring

Warning- Read these instructions fully before use, Installation should only be carried out by a COMPETENT Installer

